INSTALLATION INSTRUCTION 0001-0578-999







Style STAB 38[®] and STAB 40[®] Couplings

NOTE: You do not have to disassemble.

- 1. Clean each pipe end free of dirt, scale or coating. The gasket should seat on bare metal.
- 2. Mark pipe ends with chalk, 6" for STAB-38 and 14" for STAB-40 from each end for use as a centering guide.
- 3. Lubricate gaskets and pipe ends with soapy water (anti-freeze should be added in freezing weather.)
- 4. Slip coupling on one pipe end. Stab the other pipe end into coupling until it contacts other pipe end then withdraw pipe end 1/2" to 1" to allow for pipe deflection and expansion.
- 5. Center coupling between chalk marks.
- 6. Tighten nuts with ratchet wrench, applying only one or two turns to a nut at a time, proceeding from bolt to bolt around the pipe until all bolts are tightened to 80 ft. lbs. minimum.

Part No. 0001-0578-999 12.2018

INSTALLATION INSTRUCTION 0001-0578-999








Style STAB 38[®] and STAB 40[®] Couplings

Maximum Recommended Deflection:

2" I.D. Coupling: 6° 3" thru 12" I.D. Couplings: 4° (Take deflection after tightening.)





Dresser™ Pipeline Solutions

41 Fisher Avenue Bradford, PA 16701 P: 814.362.9200 F: 814.362.9344

www.dresserngs.com

© 2018 Natural Gas Solutions North America, LLC
The Dresser Logo and all Trademarks containing the term "Dresser"
are the property of Dresser, LLC, a subsidiary of Baker Hughes, a GE Company.

Part No. 0001-0578-999 12.2018